



PARALLEL BEAM

VACUUM PRESSURE FOOT

Quick Start Guide

Quick Start (5 Minutes)

1. Confirm spindle size (65mm or 80mm).
2. Clamp adapter evenly around spindle. Do not overtighten.
3. Seat magnetic base onto adapter until fully seated.
4. Insert 2.5-inch hose cuff fully into port.
5. Lower spindle until foot contacts material. Set Z offset accordingly.

Safety Reminder:

- Power off before installation.
- Ensure secure clamping.
- Avoid aggressive hose side-load.

Recommended for thin sheet materials. Not intended for heavy roughing passes.

Full guide: scan QR code or visit parallelbeam.com/support